

**MOUNTING PROCEDURE****KIT SAVE CARTER  
TRIUMPH STREET TRIPLE R '13****TS6101-13**[WWW.BARRACUDAMOTO.COM](http://WWW.BARRACUDAMOTO.COM)

FIND THE ATTACK POINT ON THE CHASSIS VERIFYING THE RIGHT DISTANCE OF SAVE CARTER FROM THE MOTOR-BIKE.

REMOVE THE TORX LOCKING THE NUT

**RIGHT SIDE:**

USE THE THICKNESS 70 MM AND THE BOLT 10X160.  
FIX THE BOLT INTO THE KIT WITH THE ORIGINAL NUT  
REMOVE PREVIOUSLY

**LEFT SIDE:**

USE THE THICKNESS 90 MM AND THE BOLT 10X180.  
FIX THE BOLT INTO THE KIT WITH THE ORIGINAL NUT  
REMOVE PREVIOUSLY.



INSTALL THE KIT LIKE SHOWN IN THE PICTURE; SCREW AND LOCK ALL.

MOUNT THE PVC PART ONLY AFTER THE INSTALLATION PROCEDURE